



Atuador feito no ipt



Brüel & Kjær
ELECTROSTATIC ACTUATOR
UA 0023 - UA 0033

The Electrostatic Actuator is designed for pressure-response tests. Neutronics calibration of B & K condenser microphones.
UA 0023 for 4181, 32, 44, 45, 46
UA 0033 for 4133, 33, 42
UA 0023 - 25 0024 for 4133-36
UA 0033 - 25 0032 for 4133

INSTRUCTIONS

- Mount the microphone vertically on stand.
- Remove the protecting grid and if necessary clean the microphone with a very fine plate dipper from dust. Use a brush and if necessary a solvent. DO NOT press the diaphragm.
- Connect the micro-plug to the actuator.
- Apply the voltage between actuator and microphone housing.



